

Illustrated Parts List

Hobart *PoWerMaster*® 2400 400 Hz Ground Power Unit

With 28 VDC outlet (optional)



Series: 578650

Operation Manual - PoWerMaster® 2400 – 30 - 90 kVA

Illustrated Parts List




Figure: 1.0.1 Front View

Operation Manual - **PowerMaster® 2400 – 30 - 90 kVA**

Illustrated Parts List




Figure 1.0.2 Rear View

Operation Manual - **PoWerMaster®** 2400 – 30 - 90 kVA

Illustrated Parts List




Figure 1.0.3 Side View cut

Note!

In mobile and bridge mounted units, the display module and the emergency stop button are situated in a separate box.

Operation Manual - **PowerMaster® 2400 – 30 - 90 kVA**

Illustrated Parts List

Recommended Spares List

Qty.	Unit	Part No.	Description
2	EA	AM0131	Air filter
3	EA	AM0067	Air filter for plinth
10	EA	SI2066	ATO fuse
10	EA	SI2075	ATO fuse
10	EA	SI2076	ATO fuse
10	EA	KM0200	Feed-through terminal
2	EA	VN0017	Fan
3	EA	KP7087	Capacitor
1	EA	DP0222	Circuit breaker
1	EA	PS0010	DC Power Supply
1	EA	AF0403	Emergency stop, compact
1	EA	IT0032	Current Transformer
1	EA	579526	GSE Control Board
1	EA	579527	Interface board
1	EA	579532	Capacitor Board
1	EA	579536	Display
1	EA	578100	Power Module 90 kVA